Work Order ID 60711 Tuesday, July 20, 2010 11:08:10 AM SHIP Item ID: D900-619-011 Revision ID: Accept Item Name: Setup Start Bearpaw Start Date: 7/20/2010 Start Qty: 2.00 Stop Required Date: 7/20/2010 Req'd Qty: 2.00 Cust Item ID: Reference: Customer: Approvals: Process Plan: MF Date: 10-7-20 Tooling: QC:\_\_\_\_ Run Start Date: Date:\_\_\_\_\_ SPC (Y/N): Sequence ID/ Date: Stop Operation Work Center ID Set Up/ Description Tool ID Tool # Plan Draw Nbr Accept Run Hours Reject Reject Revision Nbr Insp. Code Qty Number Stamp IIN-D900-619 Α 100 0.00 Memo Document Control 0.00 Photocopy bluefile &type labels per PPP D900-619-011 110 Pick Kit 0.00 Packaging Memo Packaging 0.00 120 QC4- 100% Inspect kits for completeness QC Memo **Quality Control** 

Work Order ID 60711 Tuesday, July 20, 2010 11:08:10 AM Item ID: D900-619-011 **Revision ID:** Accept Setup Start Item Name: Bearpaw Start Date: 7/20/2010 Start Qty: 2.00 Stop Required Date: 7/20/2010 Req'd Qty: 2.00 Cust Item ID: Reference: Customer: Approvals: Process Plan: Date: Tooling: Run Start Date: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): Date: Stop Sequence ID/ Operation Work Center ID Description Set Up/ Tool ID Tool # Plan Run Hours Accept Reject Reject Code Qty Number | Stamp 0.00 Packaging Memo Packaging 0.00 Identify and pack for shipping as per PPP D900-619-011

0.00

0.00

PPP rev:

Memo

QC21- Final Inspection - Work Order Release

140

Quality Control

Insp.

Page 2

Picklist Print													
Tuesday; July 20, 20	:010 11:08:10 AM	1							The comment of the control of the co			Property and a second	
Work Order ID: 60			<del>-</del>	ANIA BINI BANK (BARK)	<b>                                   </b>							P	Page 1/
	D900-619-011		) ( <b>a</b> r ) (7		ANNINI MI Annomorphisma (1916)	- Plant   major (jam) / jam) /				• •		*	
Parent Item Name:	Bearpaw		1187	41016 (1818 1811) 68111 687		All III III III II	Al					:	
	IPP Rev:E New M	17□Blank size chai k10010 07-01- Manufacturing Met	anged on 1-03 JLN ethod 08	n Step 3⊕KJ/. LM <sup>(8-11</sup> -04 Ver	JLM[]				Start Date: 7/20. Start Qty: 2.00			ed Date: 7/20/2010	0
Component Item ID/ Item Name	Replacement Item ID	t Mfg/ Purch	Bin	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on e Hand	C 5 P 1210		Qty	Date Statu	
	A) (1) (1)	Purchased	No			110	Each	399.0000		<b>Qty</b>	Issued	Issued	·S
AN960JD4166 Washer D2182B Rubber Cushion	NAS1149D0463J	Purchased Manufactured	No No		n 114615 114784 115108		399 12 87 300 Each	252.5452	8 1	16 M/	141 of		-
D2182B060) aut 4 at 6.00° average adius Block	Mensuro Fuo lor/2v Bud per dwg per kit M	<b>\</b>	No	57410 52 <u>Location</u> ST010	30872 52649 7912 9108	9.0 242.875 242.875	P.667 P.667 P.67 P.52 P.52 Each S  Y Lo  51	Loc Code 351.0000	16	6602		J. M.	1/20

**Picklist Print** Tuesday, July 20, 2010 11:08:10 AM Work Order ID: 60711 Parent Item: D900-619-011 Parent Item Name: Bearpaw Start Date: 7/20/2010 Required Date: 7/20/2010 Start Qty: 2.00 Required Qty: 2.00 Manufactured No 110 Each 0.0000 Bearpaw, 900 D2519 Manufactured No 110 Each 36.0000 Location Loc Oty Loc Code ST456 36 56763 36 Manufactured No 110 Each 334.0000 52748 146 Location Loc Oty 36/8424 Loc Code ST017 334 MS21042L4 58568 334 Purchased No 110 Each 3,978.000 16 ر W11/827 Location Loc Oty Loc Code ST300 3978 113422 68 114523 28 114718 23 114784 1859 115108 2000 Tuesday, July 20, 2010 11:08:10 AM

Shop Packet Print

Page 2

## **Picklist Print**

Tuesday, July 20, 2010 11:08:10 AM

Work Order ID: 60711

Parent Item: D900-619-011

Parent Item Name: Bearpaw



Start Date: 7/20/2010

Start Qty: 2.00

Required Date: 7/20/2010

Page 3

Required Qty: 2.00

QS100-M24S

Purchased

No

Location

114619

114885

ST449

110

Each

Loc Oty

36

26

10

36.0000

Lancat

Loc Code

Code

m/146/9

ICA Page 19 (20 blank) of 20




Figure 32-2: Bearpaw Installation (section view)

- Additional AN960JD416 washers may be installed under the nuts to ensure 1.5-4 threads in safety on the bolts. Although not generally necessary, it is also acceptable to replace the AN4-15A bolts with longer or shorter AN4 bolts, if required.
- 7. Lower the aircraft

## 32.2 BEARPAW REMOVAL

- 1. Jack up the aircraft.
- Loosen the clamp bolts and remove the bearpaws and clamps. Ensure the skidtubes are serviceable.
- 3. Lower the aircraft.

## 32.3 WEIGHT AND BALANCE

Installation	186 1 4 4	LA	TERAL	LONG	SITUDINAL
D900-619-011 Bearpaw Installation	Weight	Arm	Moment	Arm	- Moment
The second of th	13.8 lb 6.3 kg	0.0 in 0.0 m	0.0 lb-kg 0.0 m-kg	233.3 in 5.93 m	3220 in-lb 37.4 m-ka

## 32.4 PARTS LIST

Qty	Part Number	Description					
Χ	D900-619-011	BEARPAW INSTALLATION					
4	D2182B060	RUBBER CUSHION					
<u>8</u> ; 2	D2274 / D2421 *	RADIUS BLOCK					
4	D2519	BEARPAW   CLAMP					
8	D2529	WASHER					
8	AN4-15A	BOLT					
8	AN960JD416	WASHER					
8	MS21042L4 /	NUT (OR MS21042-4)					
4	QS100M24S	CLAMP					

COPYRIGHT © 2001 BY DART AEROSPACE USA, INC.

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.

Work Order ID 60711 Tuesday, July 20, 2010 11:08:10 AM Item ID: D900-619-011 Accept Revision ID: Setup Start Item Name: Bearpaw Stop Start Date: 7/20/2010 Start Qty: 2.00 Required Date: 7/20/2010 Cust Item ID: Req'd Qty: 2.00 Customer: Reference: Approvals: Process Plan: MC Date: 10-7-20 Tooling: Run Start Date: QC: Date: SPC (Y/N): Stop Date: Sequence ID/ Operation Work Center ID Set Up/ Tool ID Tool # Plan Description Accept Reject Reject **Run Hours** Draw Nbr Code Qty **Revision Nbr** Qty Number Stamp IIN-D900-619 0.00 Memo 0.00 Document Control Photocopy bluefile &type labels per PPP D900-619-011 CHG003 110 Pick Kit 0.00 Packaging Memo 0.00 Packaging 120 QC4-100% Inspect kits for completeness 0.00 Memo 0.00 Quality Control